DVR SERVICE

DVR: It's A Beautiful Thing!

Welcome to the wonderful world of DVR, where you can forget the TV listings and watch your favorite shows when it's convenient for you. Record with the simple touch of a button, because now **you're** in charge.

Using It Is A Snap!

Remember the blinking "12:00" on your VCR? If you couldn't figure out how to set the clock, you probably didn't do a lot of recording, either. Using your DVR is different. It's so easy, anyone can do it!

DVR SERVICE

Still Have Questions?

This is meant to give you a quick look at the basics. But if you have questions, we're always here with answers. Feel free to call anytime.

1-800-888-1300

GET HOOKED

Midcontinent COMMUNICATIONS

www.midcocomm.com • 1-800-888-1300

MC24 DVRg 1207

Get To Know Your DVR

A Quick Guide To TV On *Your* Terms

GET HOOKED

Midcontinent COMMUNICATIONS

DVR 101

To Record A Program
Press [GUIDE button], highlight the program you want to record and press [RECORD button]. If you're already watching a show, press [RECORD button] to start recording.

To Stop Recording
All you have to do is press [STOP button] and follow the on-screen choices.

To Record A Series
Just highlight the series you want to record in the Program Guide and press [RECORD button] twice. From the program information screen, just select the [RECORD SERIES option].

To Control A Live Program
Want to pause what you're watching? Just press [PAUSE button]. Want to see something again? Press [REWIND button].

To Watch A Recording
Press [LIST button]. Use [ARROW UP button] or [ARROW DOWN button] to choose what you want to play and hit [OK button].

To Delete A Recording
Just press [LIST button] and highlight the show you want to delete by using the [ARROW UP button] or [ARROW DOWN button] and press [OK button]. Then use the [ARROW UP button] or [ARROW DOWN button] to highlight ERASE and press [OK button]. Confirm it by pressing [OK button] and that's all there is to it.

[ON DEMAND button] *(UR5U Model Only)*
The "I want it on my schedule" button. Takes you to the On Demand programming menu.

[INSTANT REPLAY button]
The "I wanna see that play again" button. Replays the last 7 seconds of what you're watching.

[REWIND button]
The "Did you hear that funny line?" button. Rewinds something you want to see again.

[PLAY button]
The "I'm off the phone and want to get serious about this program again" button. One push and you pick up your show where you left off.

[LIVE button]
The "Don't care what I missed and just want to see it live" button. Press here to return to the current part of a live broadcast.

[FAST FORWARD button]
The "Let's skip past this part" button. Fast forward through what you don't want to see to get to the good stuff.

[RECORD button]
The "One touch record" button. To record a show, one press of this button makes it happen.

[PAUSE button]
The "Gotta take that phone call" button. Pause what you're watching for up to an hour to take that important call.

[STOP button]
The "I'm done watching" button. Stops the program you are currently watching, or even stops a recording in progress.

[LIGHT button] *(UR5U Model Only)*
The "Show me what buttons I'm pushing" button. Press to light up the keypad.

Remote control models may vary in appearance and function.